

STEP 1: BEFORE
 AIR-PUNCH
 DOWN

FIG. 1A


STEP 2: AIR-PUNCH
 DOWN TO LOCATE
 IN POSITION

FIG. 1B

STEP 3: AIR BLOW ACTIVATED
 MASKING TAPE SEPARATED
 FROM LEADFRAME

FIG. 1C





STEP 1: AIR-PURGE
 DOWN AND FINGER WEDGE
 INSERTED INTO
 MASKING TAPE
 FIG. 2A

STEP 2: FINGER WEDGE
 MOVES UP AND GRIP ONTO
 THE MASKING TAPE
 FIG. 2B

STEP 3: FINGER WEDGE SHEAR
 DOWN AT SHEARING ANGLE TO
 REMOVE MASKING TAPE
 FROM THE LEADFRAME
 FIG. 2C



